

VERMONT NATURAL COATINGS®



Bomol Window and Trim Stain

For exterior wood trim, doors, windows, and siding.
Use on new and prestained wood.

- Protects wood from UV rays
- Paint-like surface build with the penetration of a stain
- Excellent flow and uniform color
- Low maintenance
- Custom colors available upon request

TWO INNOVATIVE COMPANIES
with a Shared Mission



Vermont Natural Coatings' revolutionary technology and 150 years of Böhme experience combine to deliver the safest, highest quality coatings in the world.
SWISS QUALITY MADE IN THE USA.

TECHNICAL DATA

<i>Description</i>	Bomol is a natural oil / waterborne hybrid stain specially formulated for doors and windows.
<i>Viscosity</i>	Thin fluid / pH 7.5-9.0
<i>Density</i>	9.18 lbs/gal at 68 °F
<i>VOC</i>	<30g per liter
<i>Coverage</i>	250-350 sq. ft. per gallon (Coverage depends on surface porosity)
<i>Color</i>	Pure Natural, Butternut, Walnut, Western Red Cedar; Clear can be applied as a maintenance topcoat
<i>Gloss</i>	Matte

USAGE

<i>System</i>	Apply first coat to all sides of the wood. Apply second coat to all exposed wood.
<i>Application</i>	White woods should be primed with Suncare 900 to protect the natural lignin. All other woods should be primed with Hydro-Oil Primer to facilitate even penetration of the stain and to increase the longevity. Hydro-Oil Primer is ideal for cedar.

Vermont Natural Coatings, Inc
www.VermontNaturalCoatings.com
info@VermontNaturalCoatings.com
(802) 472-8700 Find us on

<i>Application</i>	Brushing, rolling, or spraying is recommended. May be rolled or sprayed followed by back brushing to maintain an even finish. Do not apply in direct sunlight. Cover all sides of wood including cuts and damaged areas.
<i>Drying</i>	Dry to touch after: 6 – 8 Hours. Re-coat after 24 Hours.
<i>Cleaning</i>	After using clean immediately with soap and water.
<i>Storage</i>	Unopened in original packaging at least 12 months at min 40° F max 90° F. (After a long period of storage, check drying properties)
<i>Additional Information</i>	The final color will depend of the color of the wood and the amount of stain that is applied. Always test stain in an inconspicuous area to ensure color satisfaction.
<i>Duties on Construction site</i>	Inspect industrial pretreated wooden parts for mechanical damages, defects, or cutting edges. These must be re-coated on site to protect against water penetration. Once installation is complete, an additional topcoat is recommended.
<i>Wooden surface</i>	New and uncoated wood should be sanded to break mill glaze and to facilitate penetration of the stain. Wood moisture should be between 12-16% and should not exceed 18%.
<i>Maintenance</i>	The time between maintenance coats is directly related to the amount of UV exposure, the construction design, and the quality of the substrate. The life of the coating will be prolonged if small damages are addressed regularly. Clean properly to provide a solid intact surface for new treatment.
<i>Disposal</i>	Dispose of container and any remaining liquid product in accordance with local, state, and federal regulations. Contact local solid waste official for handling requirements.
<i>Safety</i>	Note the safety data sheet. The usual protective measures i.e. (working clothes, goggles, respirators) must be worn even when working with products containing low levels of harmful substances. Avoid contamination of ground or surface water. Keep out of the reach of children. Ensure proper ventilation during and after processing. Does not contain any irritant substances, which could be released into atmosphere. When spraying, do not breathe in spray mist.