

VERMONT NATURAL COATINGS® BÖHME

SWISS QUALITY  SINCE 1866



Böhme has been manufacturing stains and coatings in Switzerland since 1866. Now these natural hybrid-oil stains and finishes are made in the USA and available throughout North America through a partnership with Vermont Natural Coatings. The Böhme line, for both interior and exterior applications, applies, penetrates and looks like a traditional oil. These coatings clean up with soap and water, are easy to use and maintain, and are still < 30g/L VOC.



EXTERIOR SOFTWOOD PRE-TREATMENT **Suncare 900**

TWO INNOVATIVE COMPANIES
with a Shared Mission



Vermont Natural Coatings' revolutionary technology and 150 years of Böhme experience combine to deliver the safest, highest quality coatings in the world.
SWISS QUALITY MADE IN THE USA.

Suncare 900 protects the lignin in wood and provides enhanced UV protection. Suncare 900 is an exterior pre-treatment for new or bare softwood. It penetrates deeply to provide a beautiful uniform look and increases the life of the topcoat.



Vermont Natural Coatings, Inc
www.VermontNaturalCoatings.com
info@VermontNaturalCoatings.com
(802) 472-8700 Find us on 

VERMONT NATURAL COATINGS®

BÖHME

SUNCARE 900

Through an innovative manufacturing process, Böhme harnesses the strengths of natural oil finishes into a safe, premium waterbased product.

RECOMMENDED USES:

Provides enhanced UV protection and uniform topcoat look. Can be used on new or bare softwood.



Available in Quart, Gallon,
and Five Gallon

- Extends the life of topcoats
- Helps softwoods achieve uniform color
- Enhanced UV protection
- Clean up with soap and water



• Premium Exterior Stains & Finishes •

PREPARATION & APPLICATION



SURFACE PREPARATION: Surfaces must be thoroughly cleaned and dried. Ideal as a pre-treatment for whitewoods and softwoods. For use on untreated new or bare exterior wood.

APPLICATION:

Apply when no rain is expected for 24 hours.



1) Stir well prior to use.



2) Always test the finish on a sample piece of wood to confirm the desired appearance.



3) Apply with brush, paint pad, roller or spray.



4) One coat is recommended on all sides of wood.

5) Apply evenly with the grain and always maintain a wet edge. If rolling, follow with brush or paint pad.



6) For best results apply in temperatures between 45°-80°F and relative humidity of 40%-60%. Do not apply when rain is expected within 24 hours.

7) Product will be ready for topcoat after 4-6 hours. One gallon will cover approximately 300 - 400 sq. ft. depending on porosity of wood.

TECHNICAL DATA

Color in Container	Slightly yellow hue
Clarity (Dry)	Semi-Transparent
Chemical Resistance	No visual defects
VOC	Coating: 30g/L (wet)
Flash Point	None
Freeze/Thaw Stability	Do not freeze
Pot Life	12 months from date of manufacture
Dry Time	4-6 hours
Clean Up	Soap and water
Odor	Neutral
Maximum Cure	One week
Coverage	300 - 400 sq. ft. per gallon

Vermont Natural Coatings, Inc
info@VermontNaturalCoatings.com
(802) 472-8700 Find us on

For project ideas and testimonials visit: www.vermontnaturalcoatings.com